Model Name	Left Sliders	Back Left	Back Left	Left Switch	Mid-left Switch	Left Pot	LV Trim	LH Trim	Left Trim	Right Trim	RT Trim	RV Trim	Right Pot	Mid Right Switch	Right Switch	Back Right	Back Right	Right Sliders
Devo 6s			(SW A 0/1/2)	Mix 0/1/2	Gear 0/1		TRIMLV+/ TRIMLV-	TRIMLH+/ TRIMLH-	(TRIML+/ TRIML-)	(TRIMR+/ TRIMR-)	TRIMRH+/ TRIMRH-	TRIMRV+/ TRIMRV-		D/R 0/1	FMOD 0/1/2	(SW B 0/1/2)		
Devo 7e				Hold 0/1	(SW A 0/1/2)		TRIMLV+/ TRIMLV-	TRIMLH+/ TRIMLH-			TRIMRH+/ TRIMRH-	TRIMRV+/ TRIMRV-		(SW B 0/1/2)	FMOD 0/1			
Devo 8			Rud D/R 0/1	Ele D/R 0/1	Gear 0/1		TRIMLV+/ TRIMLV-	TRIMLH+/ TRIMLH-	TRIML+/ TRIML-	TRIMR+/ TRIMR-	TRIMRH+/ TRIMRH-	TRIMRV+/ TRIMRV-		Mix 0/1/2	Ail D/R 0/1	FMOD 0/1/2		
Devo 10			Rud D/R 0/1	Ele D/R 0/1	Gear 0/1	Aux 4	TRIMLV+/ TRIMLV-	TRIMLH+/ TRIMLH-	TRIML+/ TRIML-	TRIMR+/ TRIMR-	TRIMRH+/ TRIMRH-	TRIMRV+/ TRIMRV-	Aux 5	Mix 0/1/2	Ail D/R 0/1	FMOD 0/1/2		
Devo 12s	Aux2 Aux4	HOLD 0/1	Rud D/R 0/1	Ele D/R 0/1	Gear 0/1	Aux 6	TRIMLV+/ TRIMLV-	TRIMLH+/ TRIMLH-	TRIML+/ TRIML-	TRIMR+/ TRIMR-	TRIMRH+/ TRIMRH-	TRIMRV+/ TRIMRV-	Aux 7	Mix 0/1/2	Ail D/R 0/1	FMOD 0/1/2	TRN 0/1	Aux3 Aux5
Devo 12E			Rud D/R 0/1	Ele D/R 0/1	Gear 0/1	Aux4 Aux5	TRIMLV+/ TRIMLV-	TRIMLH+/ TRIMLH-	TRIML+/ TRIML-	TRIMR+/ TRIMR-	TRIMRH+/ TRIMRH-	TRIMRV+/ TRIMRV-	Aux6 Aux7	Mix 0/1/2	Ail D/R 0/1	FMOD 0/1/2		
Devo F12e	Aux4 Aux5		Rud D/R 0/1	Ele D/R 0/1	Gear 0/1		TRIMLV+/ TRIMLV-	TRIMLH+/ TRIMLH-	TRIML+/ TRIML-	TRIMR+/ TRIMR-	TRIMRH+/ TRIMRH-	TRIMRV+/ TRIMRV-		Mix 0/1/2	Ail D/R 0/1	FMOD 0/1/2		Aux6 Aux7
Devo F7			Hold Trn	Gear 0/1		Aux 2	TRIMLV+/ TRIMLV-	TRIMLH+/ TRIMLH-			TRIMRH+/ TRIMRH-	TRIMRV+/ TRIMRV-			D/R 0/1	FMOD 0/1/2		